



PTS & PTM Dual Trigger Overview

A secondary trigger for use with all PTSTM and PTM tools that easily attaches between the tool's air inlet port and hose. This requires the operator to use both hands to run the tool and so reduces the risk of hands getting trapped between the reaction bar and reaction point.

- Inlet 1/2" BSPP Female
- Outlet 1/2" BSPP Male

To order a pre-assembled tool add the suf x .DTM onto the end of the part number. When fitting a DTM the torque tool must be recalibrate with the DTM in place.

Dual Trigger Module

SKU	Description
19286	Dual Trigger Module for use with any PneuTorque